

1 2 3 4

9. EXPLODED VIEWS AND PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The \triangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to ∇ mark on product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION

Exploded view of the top panel components:

- 9: LWSYXJ only
- 8: XJCN only
- 7: LWSYXJ, UXJCB only
- 6: LWSYXJ, UXJCB only
- 3 or 4 or 5: DEL-RZX
- 10: 13
- 11: 14
- 12: 15
- 23: 23

Main exploded view of the DDJ-RZX unit and its packaging:

- 16: DEL-RZX
- 18: Front panel
- 17: Main chassis
- 19: Connector
- 20: Component
- 21: Protective case
- 22: Shipping box

88

1 2 3 4

DDJ-RZX

(1) PACKING SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠	1 Power Cord	See Contrast table (2)	NSP 9	Warranty	See Contrast table (2)
	2 USB Cable	DDE1128	NSP 10	rekordbox dj license key card	DXA2304
	3 Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP 11	rekordbox dvs license key card	See Contrast table (2)
	4 Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP 12	rekordbox video license key card	DXA2323
	5 Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP 13	Software license notice	DRM1410
	6 License Caution	See Contrast table (2)	NSP 14	Leaflet	See Contrast table (2)
	7 License Caution	See Contrast table (2)	NSP 15	Leaflet	DRM1415
	8 License Caution	See Contrast table (2)	NSP 16	Polyethylene Bag	AHG7117
			17	Mirror Mat	DHL1201
			18	Pad	DHA1949
			19	Pad	DHA1950
			20	Pad	DHA1951
			21	Packing Case	See Contrast table (2)
			22	Carton	See Contrast table (2)
			NSP 23	Other Card	See Contrast table (2)

(2) CONTRAST TABLE

DDJ-RZX/LWSYXJ, UXJCB and XJCN are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>DDJ-RZX /LWSYXJ</u>	<u>DDJ-RZX /UXJCB</u>	<u>DDJ-RZX /XJCN</u>
⚠	1	Power Cord	ADG1244	DDG1108	DDG1114
	3	Operating Instructions (Quick Start Guide)(En, Fr)	Not used	DRH1344	Not used
	4	Operating Instructions (Quick Start Guide) (En, Fr, De, It, NI, Es, Pt, Ru)	DRH1345	Not used	Not used
	5	Operating Instructions (Quick Start Guide)(Zhc)	Not used	Not used	DRH1347
	6	License Caution (En, Fr, De, It, NI, Es, Pt, Ru, Ja, Zhtw)	DRH1387	DRH1387	Not used
	7	License Caution (Fr)	DRH1388	DRH1388	Not used
	8	License Caution (Zhtw, Ko)	Not used	Not used	DRH1389
NSP	9	Warranty	DRY1270	Not used	Not used
NSP	11	rekordbox dvs license key card	DXA2322	DXA2322	Not used
NSP	14	Leaflet	DRM1414	DRM1414	Not used
	21	Packing Case	DHG3468	DHG3466	DHG3472
	22	Carton	DHG3469	DHG3467	DHG3473
NSP	23	Other Card	Not used	DRM1413	Not used