


W47

# C FLUTE

## JFL-510RE



## Parts list

ref_no	parts	Part_desc
1	51-U0003S	Bow headjoint ass'y
2	51-N0020S	Straight headjoint ass'y
3	51-N001S	Flute head stopper screw
5	51-C101	Flute head stopper cork
6	51-N601	Flute head stopper nut
7	51-N404S	Flute head crown
10	51-D0120S	Bodyass'yw/outkeys
11	51-D409S	Body joint ring
12	51-W0017S	Key post ass'y
14	51-W0013S	Key post ass'y
15	51-W0052S	Key post ass'y
16	51-K0137S	D# trill key
17	51-K0138S	D trill key
18	51-K0152S	D# trill key lever
19	51-K0302S	C key
20	51-K0289S	Bb thumb lever
21	51-K0288S	B key
22	51-K0140S	Bb key
23	51-K0159S	A key
24	51-K0155S	Duplicate G# key
25	51-K0143S	G key
26	51-K0161S	G# key
28	51-K0145S	F# key
29	51-K0162S	F key
30	51-K0156S	E key
31	51-K4008S	Joint key
32	51-K0164S	D key
33	51-D0100S	C footjoint ass'y w/out key
34	51-W0055S	Key post ass'y
35	51-K0149S	D# key
36	51-A102S	Low C & Low B key roller
37	51-C215	Low C key roller screw
38	51-K0150S	Low C# key
39	51-K0151S	Low C key
41	51-P002	Pad set
42	51-A301	Pad metal washer for
43	51-C202	Pad screw
44	51-C008	Rod screw set
45	51-C014	Shaft set
46	51-C205	Pivot screw
47	5A-C2003	Adjusting screw
48	51-S004	Needle spring set for E/RE
49	51-A5002	Knock pin
50	51-S101	Flat spring
51	51-A0001	Felt set
52	51-C109	Trill key bumper
53	51-C201	Adjusting screw
54	51-C111	D# key bumper
55	51-C204	Flat spring screw
56	51-A0003	Metal Plug set
57	51-A9003	Metal plug remover