



Each time you press the button, its color changes.

Red	Concert Piano
Green	Stage Piano
Blue	Magical Piano
Pink	Vintage EP
Light blue	Harpsichord
Yellow	Church Organ 1

Records a song.

Plays/stops the song.

* When recording, this starts/stops song recording.

Turns the metronome on/off.

* The button lights up when Bluetooth is connected.



Internal song list

1	Valse romantique	7	Salut d'Amour	13	Mazurka No.5	19	An die Freude (Jazz Arrangement)	25	Sicilienne (Jazz Arrangement)
2	La Fille aux Cheveux de Lin	8	Zhavoronok	14	Nocturne No.2	20	Paganini boogie	26	Swan-derful Samba
3	Reflets dans l'Eau	9	Die Forelle	15	Nocturne No.20	21	The Nutcracker "Waltz of the Flowers" (Jazz Arrangement)	27	My Pleasure
4	1ère Arabesque	10	Barcarolle	16	Für Elise	22	Floral Pursuits	28	Windy Afternoon
5	Jeux d'eau	11	Träumerei	17	Amazing Grace	23	Canon (Jazz Arrangement)	29	Bop On The Rock
6	Je te veux	12	Auf Flügeln des Gesanges	18	Jupiter from The Planets (Jazz Arrangement)	24	Late Night Chopin	30	Trio Grande

Song selection

Song settings

Built-in songs															USB flash drive										Song volume		SMF play mode		Play all songs mode																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Recorded songs		Save recorded song to USB flash drive		-		+		Default value		Built-in songs		External data		Auto-select (default)		Off		By song (default)		Random																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
C1					C2					C3					C4					C5					C6					C7																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					

Sound and keyboard settings

Metronome settings

Other settings

★ Ambience		★ Brilliance		★ Master tuning		○ Down-beat		Time signature (beat)		Standard tempos		Tempo		○ Metronome volume		○ Notification sound volume		○ USB/Bluetooth audio volume		○ Bluetooth		○ Auto-off	
Reverberation of sound		Brightness of sound		Pitch adjustment																			
-	1 (default)	-	0 (default)	Fixed	Very light	-0.1 Hz	0 (default)	On	2	Lento (52)	-	5 (default)	Low	Off	-	Bluetooth pairing	20 min. (default)						
+	On (default)	+	0 (default)	Light	Normal (default)	+0.1 Hz	0 (default)	Off (default)	4	Andante (72)	+	5 (default)	High	Off	+	On (default)	Off						
	Off		0 (default)	Heavy	Very heavy		0 (default)		6	Andantino (80)		5 (default)				Off							
			0 (default)				0 (default)		7	Moderato (96)		5 (default)											
			0 (default)				0 (default)			Allegretto (108)		5 (default)											
			0 (default)				0 (default)			Allo.Moderato (120)		5 (default)											
			0 (default)				0 (default)			Allegro (132)		5 (default)											
			0 (default)				0 (default)			Allo.Vivace (152)		5 (default)											
			0 (default)				0 (default)			Vivace (160)		5 (default)											
			0 (default)				0 (default)			Prestissimo (200)		5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											
			0 (default)				0 (default)					5 (default)											

Download the app



Roland Piano App

For iOS/iPadOS/Android devices



Online manual (Web)



https://roland.cm/kf-20-25_om

Saving your settings

The star (★) mark indicates settings that can be saved so that they don't change when you turn the power off and on again.

1. Press the **[▶/■]** button while holding down the **[Δ]** button.



2. Press the [▶/■] button again.

The settings marked with a circle (○) mark are saved automatically, so you don't need to save them yourself.

Restoring the unit to its factory state

1. Turn off the power.
2. Turn on the power while holding down the [] button, and keep holding down the [] button (for around five seconds) until the button blinks.



3. Press the [] button again.
4. When all buttons are blinking, turn the power off and then on again.