


Klowra Mantra Dual Footswitch

OPERATING GUIDE





Overview

This guide explains how to set up the **Klowra Animus Dual Footswitch** for use with **Klowra Bloom Infinity** series pedals. The connection and setup process is the same for all models in the series. The **Klowra Limbo Reverb** is used as the example below.

If you plan to use the **Klowra Animus Dual Footswitch** with other devices, please refer to the user manual for the specific device.

Connection and Activation

Depending on your output jack, use one of the following methods to connect to the Limbo Reverb:

- **TRS Jack:** Connect one end of the included 1/4" (6.35 mm) TRS cable to the TRS jack.
- **A or B Jacks:** Connect one end of the included 1/4" (6.35 mm) TS cable to the A or B jacks.

Next Steps:

- Connect the other end of the cable to the **CTRL** jack on the Limbo Reverb.
- Once connected, the Limbo Reverb will flash red and automatically enter Calibration Mode.

Tip: Always use a TRS cable for the TRS jack. Using a TS cable may prevent the device from being detected or cause incorrect control ranges.



Calibration

Once connected, the Limbo Reverb indicator will flash red to indicate Calibration Mode. While in this mode, repeatedly tap all the footswitches on the *Animus*.

The device will automatically exit Calibration Mode after approximately 5 seconds, at which point it is ready for normal operation

Not working after calibration?

If the pedal does not respond correctly after calibration, try the following:

- Unplug and reconnect the cable on both ends.
- Confirm the *Animus* is connected to the TRS jack and the *Limbo Reverb* is connected to the CTRL jack.
- Re-enter Calibration Mode and immediately tap **all the switches** on the *Animus* quickly and repeatedly.
- If the issue persists, try a different 1/4" (6.35 mm) TRS cable.

TRS MAP Switches

Assigns the footswitches to the TRS jack contacts.

Settings:

- T:A / R:B
- T:B / R:A

(T = Tip, R = Ring)

Note: This switch setting does not affect the signals on the A jack and B jack outputs




Connection examples

Triple outputs:

Each output jack functions independently to utilize the special features of Klowra pedals.

In the example below, the **TRS MAP** is set to **T:A / R:B**.



With the **Limbo** (left)'s LED set to **White** and the **Sprout** (right)'s LED set to **Orange**:

- Footswitch **A** simultaneously controls the **RAMP** of the Limbo and Everlast (center).
- Footswitch **B** simultaneously controls the **TAP Tempo** of the Everlast and Sprout.



Where Every Tone Blooms.