

rapture

Rapture takes the complete drive section from Triptychon, its amplifier-foundation stage and brings it into a dedicated standalone overdrive with an expanded range of control. Its design draws from the qualities we value most in classic tube amplifiers when they are pushed into their sweet spot: natural compression, harmonic development, touch sensitivity and the gradual transition from clean to breakup. Expanding on the original Triptychon drive concept, Rapture adds two interactive toggle switches, MORE and MOD, which extend the gain structure and reshape the way the circuit reaches and responds to breakup.

Controls:

drive: set the amount of gain and the intensity of the amplifier-like compression and breakup. Lower settings emphasize harmonic richness, touch response and subtle enhancement; higher settings move further into pushed overdrive.

tone: shape the tonal balance of the overdrive while retaining the fundamental character of the guitar and amplifier.

master: set the overall output level. Use it around unity level for subtle enhancement or turn it up to push the following amplifier or gain stage harder.

MORE: extend the available drive and gain behavior. Its effect depends on the drive setting and on the position of MOD, creating a more pushed version of the same core voice rather than a separate channel.

MOD: change the clipping behavior of the circuit. In the MODified position, clipping is reduced and the response becomes more open, moving the feel toward the compression and breakup associated with a tube amplifier being pushed near the limits of its clean headroom.

MORE + MOD INTERACTION

MORE and MOD are interactive. Their character changes with each other and with the drive control setting, producing subtle but meaningful variations in headroom, compression, harmonic content and playing feel.

Set both MORE and MOD to the down position for the exact original Triptychon drive section circuit / sound.

FOOTSWITCH / BYPASS

Press the soft-click footswitch to engage or bypass Rapture. The effect uses true bypass switching via a high-quality relay.

Power-up bypass state preset:

On power-up the LED will blink and then go in bypass mode by default. Hold the footswitch during power-up to change the default function to engaged (on state). Repeat the procedure above to restore the previous setting.

CONNECTIONS

↓: connect your guitar or the output of the previous effect pedal

↑: connect to the input of your amplifier or the next effect pedal

⚡ Use 9-18V DC center negative, regulated / stabilized and filtered (not included). Do not use more than 18V DC as it will cause malfunction and void warranty. Isolated power supply is strongly recommended for optimum performance.

Current consumption: 50mA minimum

Warranty: Rapture comes with 5 years warranty from date of manufacture. We will provide service/repair at no labour or internal parts cost within 5 years from date of manufacture - buyer is responsible for all shipping costs and/or customs fees and taxes that may apply. This warranty excludes normal cosmetic wear and damages done due to misuse or improper handling.

Contact info:

info@crazytubecircuits.com

Visit our website:

www.crazytubecircuits.com

